

## **MAD ROBOT**

#### **HOW TO ORDER**

A complete MAD ROBOT remote controlled target system consists of three main components:

### **TARGET**

# TARGET MOUNTING ADAPTER

### MAD ROBOT R/C PLATFORM



The following steps illustrate the procedure for specifying all of the components you will need.

Step 1: Select the basic MAD ROBOT model based on the types of surfaces where it will be used: MR2 for for flat, smooth surfaces like concrete, asphalt or short grass; MR3 for uneven outdoor terrain, gravel or tall grass.

Step 2: Add MAD ROBOT options like SHOCK DAMPERS (MR Option D) for heavier Targets or for impact weapon or less-than-lethal munitions training. Add TANDEM WHEELS (MR Option T) if the MAD ROBOT will be operated on loose surfaces, like gravel or soft dirt.

- Step 3: Select the Target (or Targets) you plan to use with your MAD ROBOT.
- Step 4: Select the required Target Mounting Adapter to attach your selected Target to the MAD ROBOT platform.
- Step 5: Optionally, add Target Accessories and Target Clothing to vary your scenarios and add realism.

Finally, place your order with an authorized dealer near you or directly with the USAI factory. Contact United Service Associates, Inc. if you have any questions.